

Speed Nok

with peep aligner

INSTRUCTIONS:

1. Replace brass nock with a Speed Nok.
2. Align peep with the peep-aligner tail between the arrow nock on the far side of the bowstring.
3. Fasten securely using Blue Loc-Tite (#242) with a #0 Phillips screwdriver.
4. If peep is not aligned at full draw, loosen and rotate Speed Nok in that direction and re-tighten.



WARNING: Re-check screw tightness after use.

TOMORROW'S RESOURCES UNLIMITED, INC.
PO BOX 1180, MADISON HTS., VA 24572

T.R.U. SPEED NOK (TBSN-BK)
with peep aligner